

mini-Ligno S/D and S/DC

Before taking a measurement remove the green cap and place it on the other end of the meter. The cap fits your hand for easy pin insertion. To obtain a reading, push pins into wood. As soon as on-off switch is depressed, red numbers indicate moisture readings. For deeper measurements use longer pins (stored in the back of the case).



Wood: Moisture readings are indicated in percent and corrected for wood temperatures of 70°F (20°C). For higher or lower wood temperatures use table in manual. Wood species and corresponding wood group settings are listed on the back. Contact customer service for unlisted species.



Building Materials: Setting 1 is for sheetrock and gypsum. Moisture readings are in percent. Setting 0 is a reference scale for all other building materials. See manual pages 1.3 and 2.2.

Check/change settings: Wait until meter is off. Then double click on-off switch between pins by hand. A red number indicates setting between 0 and 3. While setting is displayed, click on/off switch again to change setting. Wait until meter is off before taking readings.

When LED lights get dim, exchange 9 V battery. Remove screw on back, open into 2 halves.

Lignomat USA Ltd 14345 NE Morris Ct.
Portland OR, 97230 USA www.lignomat.com
Tel: 503-257-8957 e-mail: sales@lignomat.com

Settings for mini-Ligno S/D, S/DC

Woodgroup 2

Abachi
Acacia
Afrormosia
Bamboo
Beech
Cedar (all types)
Cumaru
Dogwood
Gonzales Alves
Iroko
Jatoba
Koa
Locust
Oak Red / White
Poplar
Ramin
Rosewood
Teak
Wenge
Zebra Wood
Hardboard
OSB
Waferboard

Woodgroup 3

Alder
Ash
Aspen
Balsa
Basswood
Birch
Cherry
Cottonwood
Cypress
Elm
Fir Douglas
Gum
Hemlock
Hickory
Kempas
Larch
Lauan (white / red)
Mahogany
Maple
Meranti (dark / red)
Merbau
Myrtlewood
Oak European
Pine
Pine Southern Yellow
Redwood
Spruce
Tigerwood
Walnut
Particleboard